

	Work Instruction:
	Release Date 27-04-20
	Rev Work Instruction V1.2
	Page 1(1)
<b>TITLE: SUB-ASSEMBLY #6B – SD-CARD SOFTWARE</b>	

Revision	Date	Modifications	Author
V1.0	20-04-20	First version and setup	Jeffrey Visser
V1.2	27-04-2020	Translation Dutch to English	Guusje Jans / Jim Smit

This manual explains how to upload the GUI-software to the SD card easily.

Part	Supplier	Pieces
(micro) SD-card	RS online	1
computer with (micro) SD-card reader	n.a.	1

- Install the image burner software from the Raspberry Pi website:  
<https://www.raspberrypi.org/downloads/>

- Make sure the computer is able to read SD-cards.

- Open 'Raspberry Pi Imager' software. Figure 3 shows the window that should open.

(3)



- Select at Operating System -> use custom -> Select the software image file called 'Ventilator pi Image.img'
- Select SD card reader at SD card and check if the size complies with used SD card.
- Select Write. The software will be written on the SD Card, this may take a few minutes.